

SPORT-TRANSFER sp. z o.o. Jawornik 564 32-400 Myślenice Tel. +48 12 649 14 83

e-mail: biuro@ sport-transfer.com.pl

INSTRUCTIONS FOR ASSEMBLY AND USE OF SPORTS EQUIPMENT

Product: BASKETBALL BACKBOARD BOTTOM EDGE PAD 90X120 CM

Code: 10 016/120, 10 116/120

The basketball backboard bottom edge pad meets the requirements of PN-EN 913:2019-3 and PN-EN 1270:2006 "Pitch Equipment – Basketball Equipment. Functional and Safety Requirements, Research Methods."

1. Product description

10 116/120

Made of polyurethane, suitable for a 90x120 cm backboard with an edge thickness of 55 mm. Attached to the backboard frame in 8 points using screws and special pins. Colour: blue, red /upon special request: black, green/.

10 016/120

A pad made of polyethylene, suitable for a 90x120 cm backboard with an edge thickness of 55 mm. Attached to the backboard frame in 8 points using screws and special pins. Colours: blue, red, green, black. Pads can be made for backboard edge thicknesses between 20 and 65 mm.

2. Purpose

Pads are used to protect the bottom edge of the board during the game. They improve safety in the use of basketball backboards. They protect against injury when playing team sports.

3. Components

Number	Name of part / component	Quantity per product
1	Backboard bottom edge pad 90x120 cm	1
2	Mounting screws	6

4. Installation of a pad for the bottom edge of the backboard

- a) Installation of the pad is carried out on a properly fixed basketball backboard.
- b) Press the pad against the bottom edge of the basketball backboard.
- c) Set the driver to the clutch screwing position.
- d) Place a self-drilling screw in the socket spanner.
- e) Drill the screw through the mounting sleeve in the cover into the backboard frame and tighten until the screwdriver clutch engages.
- f) Assemble by screwing in the screws in the side part of the padding first and then in the bottom part.

5. Using the pad

- a) The pad is designed for 90x120cm basketball backboards in sports halls and outdoor facilities.
- b) Periodically check the pad fasteners and the condition of the padding material.
- c) The pad should not be subjected to mechanical damage /cutting, notching, burning, etc./.
- d) Do not move the backboard by holding the bottom edge padding.
- e) Do not hang on to the pad.

6. Transport, storage, maintenance, disposal

- a) The pads are supplied by the manufacturer in a single cardboard box with a size of 203x55x10cm, the weight of Article No. 10 116/120 amounts to 5 kg. / article No. 10 016/120 1.5 kg.
- b) The product is intended for permanent installation not for storage.
- c) To be wiped down with a cloth dampened with a mild cleaning agent by persons with the appropriate qualifications for working at heights.
- d) Depending on local requirements, the product may be intended for recycling or energy recovery after use.
- e) The product and its accessories must be properly disposed of at an appropriate local waste disposal/recycling facility.
- f) Correct disposal will help to prevent potential negative consequences for the environment and human health and promote the recycling of materials and resources.

7. Warranty

- a) The backboard bottom edge padding is covered by a 24-month manufacturer's warranty.
- b) The warranty does not cover damage caused by improper use e.g. cutting, slashing, burning, etc.
- c) The warranty does not cover the misuse of the backboard's bottom edge padding.